



Aprilia Futura

Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

Important Installation Considerations

Works well as a riser, however, fairing and triple clamp pinch bolts restrict convertibility. Hydraulic lines top fittings need approx 30 degree bend. Riser pipe will need to be trimmed to desired rise. some models will require raising fork tube up approximately 10-15mm.

Special Kit Requirements/Installation Tips

1. Cyclops Clamps - are to be mounted on top of the triple clamp

Restrictions

1. Foreword Positions restricted by instrument panel
2. Kit works well as a riser, but there are restrictions when converting to a lower handlebar position.

Recommended Riser Trim Length

1. 8.0" Riser Length = No Trimming

Recommended parts and replacement lines

1. Hydraulic Brake Line = Stock + 3"
2. Hydraulic Clutch Line = Stock + 2"

