

BMW K1200 GT RS

Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

Important Installation Considerations

Rerouting of all the wires is necessary. Some routing ingenuity is required. Rerouting the throttle line is difficult but necessary. Grip heater wire can be run through the handlebars, but this wire may need to be lengthened. Part of the fairing needs to be removed to access and clip zip ties holding extra wire needed for rise. The install will take longer than most bikes, but the result is worth it. Stock cables may need to be sent to Motion Pro for lengthening.(7-12 day turn around)

Recommended Riser Trim Length

1. 8.0" Riser Length = No Trimming

Recommended parts and replacement lines

1. Hydraulic Brake Line Top Fitting - 000(Straight)
2. Hydraulic Brake Line = Stock + 3"

