



Ducati Monster(2002+)

Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

Important Installation Considerations

Simple Install. Re-routing of the wires and lines is necessary and some individual ingenuity is required, but the install is relatively simple and straight forward. Monsters made before 2002 however, have a taper on the fork tube that makes it impossible to mount a clip-on style handlebar to.

Recommended Riser Trim Length

1. 8.0" Riser Length = No Trimming

Recommended parts and replacement lines

1. Hydraulic Brake Line - OK
2. Throttle Lines - Ok rerouted
3. Cable Clutch Line - Ok rerouted

