

Honda CBR-900RR

Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

Important Installation Considerations

Fairing stay/windshield Frame restricts rise to 2 inches above stock. If modified or removed, more rise can be achieved.

Special Kit Requirements/Installation Tips

1. Contact - Slight fairing contact is ok as long as the steering stops can be reached without damaging the fairing
2. Reservoir Mount(s) can be carefully bent to allow more rise.

Restrictions

1. Fairing stay/windshield Frame - restricts rise. If the fairing stay is modified or removed, more rise can be achieved.

Recommended Riser Trim Length

1. 5.0" Riser Length = Trim Number 8

Recommended parts and replacement lines

1. Hydraulic Brake Line Top Fitting - 90 degree face to the side
2. Hydraulic Brake Line = Stock + 3"
3. Cable Clutch Line - Ok rerouted

