

Kawasaki ZX-6RR+636(03-04)

Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

Important Installation Considerations

Special Kit Requirements/Installation Tips

1. Contact - Slight fairing contact is ok as long as the steering stops can be reached without damaging the fairing

Restrictions

1. Upper fairing and or windshield can be trimmed for more rise.

Line Routing

1. Electrical Lines to be freed from their brackets and or Zip Ties, and run on the rider's side of the forks

Recommended Riser Trim Length

1. 6.5" Riser Length = Trim Number 11

Recommended parts and replacement lines

1. Kawasaki 6RR/636 (03-04) Stock+75mm Throttle Lines (part number X-620).
Order from ConvertiBARS
2. Hydraulic Brake Line Top Fitting - 90 degree face to the side
3. Hydraulic Brake Line = Stock + 5"
4. Throttle Lines - Stock + 2"

