

Bike Specific Install Notes and Tips

Suzuki SV650(98-02)

Restrictions

1. The stock turn signals do not allow enough room to mount the Cyclops clamps. We recommend using an after market turn signal that you like.

Special Kit Requirements/Installation Tips

1. Turn signal bracket and rubber grommet need to be trimmed to accommodate the Cyclops Clamp.(see photos below)

Replacement Lines

1. Brake Line = Stock line will allow 2 inches of rise
2. Clutch Line = Ok
3. Throttle Lines = Ok

Model Specific kit components

1. None



CONVERTIBARS™

