

Triumph Speed Triple(05+)

Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

Important Installation Considerations

Requires the 53mm Universal kit and the shim kit to reduce the clamp size to 52mm.

Line Routing

1. All longer lines routed as stock.

Recommended Riser Trim Length

1. 8.0" Riser Length = No Trimming

