



Triumph Sprint ST(02-06)

Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

Important Installation Considerations

Special Kit Requirements/Installation Tips

1. Contact - Slight fairing contact is ok as long as the steering stops can be reached with out damaging the fairing
2. Zip ties or brackets holding excess electrical lines will need to be cut or removed to free up extra length.

Line Routing

1. Throttle lines - Stock Length - Route below the brake lever

Recommended Riser Trim Length

1. 8.0" Riser Length = No Trimming

