



# Triumph Thruxton

## Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

### **Important Installation Considerations**

The stock headlight mounting sleeves interfere with the Cyclops clamps, so you can either trim down the stock headlight mounting sleeves, or replace the stock sleeves with the sleeves listed in the kit below.

### **Special Kit Requirements/Installation Tips**

1. Zip ties or brackets holding excess electrical lines will need to be cut or removed to free up extra length.

### **Recommended Riser Trim Length**

1. 8.0" Riser Length = No Trimming

### **Recommended parts and replacement lines**

1. Hydraulic Brake Line Top Fitting - 90 degree face to the side
2. Hydraulic Brake Line = Stock + 3"

