

Yamaha YZF-R1 (04-06)

Bike Specific Install Notes and Tips

This is an aftermarket product that fits up different than the stock components, therefore, the installer may be required to set up components and to route lines in the "best way possible", which may not always be listed on this "Bike Specific" installation sheet. In any case, the installation must allow the handlebars to reach both steering stops, without pulling taught or kinking any lines, and without damaging any part of the motorcycle

Important Installation Considerations

The stock steering damper cannot be used with the ConvertiBARS. Stock steering damper can be used with an aftermarket fork mount, but may restrict positioning of ConvertiBARS. A top mount steering damper is recommended. Up to 5" of rise can be achieved by Trimming the fairing and ordering a longer brake line.

Special Kit Requirements/Installation Tips

1. Contact - Slight fairing contact is ok as long as the steering stops can be reached with out damaging the fairing

Handlebar Positioning

1. When the bars are in the down position, with the wheel straight, the clamps should be rotated so the handlebar risers are at approximately the 10 and 2 - O'Clock positions(as the rider is looking down at the top of the fork tubes) This will allow clearance with fairing side pieces as you turn stop to stop.
2. When the bars are in the up position, with the wheel straight, the clamps should be rotated so the handlebar risers are at approximately the 7 and 5 - O'Clock positions(as the rider is looking down at the top of the fork tubes) This will allow clearance with the upper fairing and windshield as you turn stop to stop.
3. Some positioning will require having the Cyclops Clamps mounted down the fork tubes away from the triple clamp.

Restrictions

1. Upper fairing and or windshield can be trimmed for more rise.

Recommended Riser Trim Length

1. 6.5" Riser Length = Trim Number 11

Recommended parts and replacement lines

1. Yamaha R1 (04-08) Stock+50mm length Clutch Line. Part Number X-627. Order from ConvertiBARS.
2. Hydraulic Brake Line Top Fitting - 90 degree face down
3. Hydraulic Brake Line = Stock + 3"
4. Throttle Lines - Ok rerouted
5. Cable Clutch Line - Ok rerouted

